## **JOBE #-5114 Le Trap Sluice Stand Parts List**

- 4 Legs
- 2 Cross members
- 2 center rods
- 2 center rods w/ attachment points
- 2 straight caps to hold the sluice down on the intake end
- 2 angled caps to hold the sluice down on the discharge end









