## **JOBE #6501 Universal Sluice Stand Instructions**



4 Leg Brackets2 Leg Bracket Braces





Hardware Pack



4 Legs







Use one of the Leg Bracket Braces as a template to mark the location of the bolt holes on your sluice. Drill the holes with a 1/4 inch bit. Make sure that the location of the holes will not interfere with your ability to remove the riffles for cleanup.

The Leg Bracket Braces are optional. Use them on the front (discharge end) legs to stiffen up the front of the sluice.

Mount the Leg Brackets to your sluice using the 1/4 inch nuts, bolts, and washers provided in the hardware pack. The angle of each leg can be independently adjusted. Normally the front (discharge end) legs are angled so that the stand is stable with the normal operating angle of the sluice. Use the 4 angle bolts to adjust the height of each leg independently.

